

愛知県高潮浸水想定区域図

津島市 086



A scale bar at the bottom right of the page, showing a horizontal line divided into four segments. The first segment is black, followed by three white segments. Numerals '0', '50', and '100' are placed above the first, second, and third segments respectively. A small 'm' is positioned at the far right end of the scale bar.